

Dear Customer,

Thank you for your recent purchase from www.handiworld.com.

Within the Fitting & Safety Instructions leaflet included with your HandiRack, you will note that we provide guidelines as to what steps you should take when using the HandiRack in wet weather conditions. We have now developed an additional measure which is included with your order.

- 4 x Cellulose Sponges
- 4 x TPU covers

This simple to fit accessory absorbs moisture that may wick down the HandiRack's fitting strap when extreme or heavy rain is encountered. The cellulose sponges have a high absorption characteristic. The TPU covers are designed to protect the headlining of the car from moisture.

Instructions for Use

- As detailed in the HandiRack Fitting & Safety Instructions (Using the HandiRack in Wet Conditions), secure the V flaps to the underside of both HandiRacks using the Velcro pads
- Lay the HandiRacks across the roof of the car deflated
- Moisten the sponges (simply rinse in water and then squeeze dry)
- Slide one sponge through the channel that runs along the top of each door frame rubber seal (Image 1). You may need to press the sponge down a couple of times to ensure that it's securely held in place. Repeat for all 4 or 2 doors.
- When placing the TPU covers onto the HandiRack fitting strap, remember to place two of them on each strap. One for the off-side and the other for the near-side of the car. The covers should then be positioned just under the door frame (Image 2).
- Once both covers are positioned on the fitting strap, continue to secure the HandiRack to the roof of the car following the Fitting & Safety Instructions
- With the HandiRack now tightened and inflated make sure that when the doors are closed and that the sponges are centred over the fitting strap (Image 3).



Image 1



Image 2



Image 3